


## WIRING DIAGRAM - EPC12HW

## Pump Controller for CH and DHW system



Ē	Battery powered	PE 📥	Ground (electricity)	(((	Wireless communication
	Fuse		Pump	<b>\$\$\$</b>	Heating mode
L, N	230V AC power supply	M	Valve actuator	S	Occupancy sensor or ON/OFF contact
COM, NO, NC	Voltage-free output	T	Temperature sensor	S1, S2	Input terminals
۲	Boiler - Boiler connection * - Boiler's contacts for ON/OFF thermostat (according to the boiler's instructions)	E30NC	Thermoelectric actuator	SL →	230V AC voltage output

LEGEND

## www.engocontrols.com