


## WIRING DIAGRAM - EIRTXWIFI

## Wi-Fi IrDA Transmitter



## LEGEND

Ē	Battery powered	PE 📥	Ground (electricity)	(((	Wireless communication
-	Fuse		Pump	<b>\$\$\$</b>	Heating mode
L, N	230V AC power supply	M	Valve actuator		NC/COM/NO switch
COM, NO, NC	Voltage-free output	T	Temperature sensor		Contact normally open NO
S1, S2	Input terminals	E30NC	Thermoelectric actuator	_/_	Contact normally closed NC
SL →	230V AC voltage output	٢	Boiler - Boiler connection * - Boiler's contacts for ON/OFF thermostat (according to the boiler's instructions)		

## www.engocontrols.com